

## transEDIT™ Lentiviral gRNA plus Cas9 (pCLIP-All) Target Gene Sets

Bacterial Glycerol Stock

CAHS1001, CAMS1001, CARS1001

This manual provides information for the propagation, transfection, transduction and viral packaging of the transEDIT lentiviral gRNA plus Cas9 (pCLIP-All) lentiviral vectors. It also includes viral transduction protocols for these vectors. Appendix 2 contains basic safety information for production and handling of lentiviral particles. Review local safety guidelines for complete regulations

### 1. Introduction

Clustered regularly interspaced short palindromic repeats (CRISPR)/CRISPR-associated (Cas) systems were originally discovered as part of a prokaryotic adaptive immune system to protect against invading viruses and bacteriophages. The type II CRISPR/Cas system found in *Streptococcus pyogenes* has been well-studied, and is comprised of a CRISPR-associated (Cas9) endonuclease that complexes with two small guide RNAs, crRNA and tracrRNA, to make a double-stranded DNA break (DSB) in a sequence specific manner (Reviewed in Charpentier & Doudna, 2013). The crRNA and tracrRNA, which can be combined into a single guide RNA (gRNA), directs the Cas9 nuclease to the target sequence through base pairing between the gRNA sequence and the genomic target sequence. The target sequence consists of a 20-bp DNA sequence complementary to the gRNA, followed by trinucleotide sequence (5'-NGG-3') called the protospacer adjacent motif (PAM). The Cas9 nuclease digests both strands of the genomic DNA 3-4 nucleotides 5' of the PAM sequence. By simply introducing different guide RNA sequences, the Cas9 can be programmed to introduce site-specific DNA double-strand breaks virtually anywhere in the genome where a PAM sequence is located. The double-stranded break at the target site induces DNA repair mechanisms, such as non-homologous end joining (NHEJ) that create insertions and deletion (indels) leading to a premature stop codon, and homology-directed recombination (HR) for introducing or knocking in new sequences (Figure 1). Gene knockouts or knockins can be efficiently created in many different cell lines opening up unprecedented opportunities for targeted genome editing and cell engineering.




Figure 1. Schematic representation of RNA-guided double-stranded DNA cleavage by CRISPR/Cas9 using a programmable guide RNA.

## 2. Lentiviral gRNA plus Cas9 (pCLIP-All) vector information

The pCLIP-All expression vector allows transient and stable transfection; as well as the stable delivery of the both into host cells via a replication-incompetent lentivirus.

- Transduction of primary and non-dividing cells
- Fluorescent marker for direct detection expression
- Puromycin or blasticidin resistance for enrichment of transduced cells




Figure 2. Schematic of the basic elements of the pCLIP-All lentiviral vectors. Multiple promoters and selection markers are available.

Vector Options	Description
EFS	elongation factor-1 $\alpha$ short promoter
hCMV	Human cytomegalovirus promoter
Blast <sup>R</sup>	Blasticidin resistance
Puro <sup>R</sup>	Puromycin resistance
ZsG	ZsGreen fluorescent protein
tRFP	TurboRFP (red fluorescent protein)

## 3. Replication protocols for glycerol stocks

### Materials for individual and plate replication

LB-Lennox Broth (low salt)	VWR EM1.00547.0500
Glycerol	VWR EM-4760
Carbenicillin	VWR 97063-144
96-well plates	VWR 62407-174
Aluminum seals	VWR 29445-082
Disposable replicators	Genetix X5054

## Propagate culture for storage

pCLIP-ALL lentiviral cultures should be propagated in LB broth with ampicillin or carbenicillin (100 µg/ml) at 30°C for 30 hours or until the culture appears turbid. 2-10 ml starter cultures can be inoculated using 2 to 10 µl of the glycerol stock provided. Once turbid, place 920 µl of culture into a polypropylene tube and add 80 µl sterile glycerol (8% glycerol). Mix well and store at -80°C. Glycerol stocks kept at -80°C are stable indefinitely as long as freeze/thaw cycles are minimized.

## 4. Plasmid preparation

For transfection and transduction experiments the pCLIP-All plasmid DNA will first have to be extracted from the bacterial cells. Cultures should be grown in LB broth with ampicillin or carbenicillin (100 µg/ml) at 30°C for 30 hours or until the culture appears turbid. 2-10 ml starter cultures can be inoculated using 2 to 10 µl of the glycerol stock provided. Either a standard plasmid mini-preparation or one that yields endotoxin free DNA can be used. When isolating plasmid DNA for virus production using endotoxin free kit will generally yield higher viral titers.

## 5. Selection kill curve

The optimal antibiotic concentration should be determined for a cell line prior to transduction or transfection. The pCLIP vector has an option for puromycin or blasticidin selection in mammalian cells. To establish stable cell lines, once transfection/transduction has occurred, the cells can be placed on puromycin to select for stable integrants. Since cell lines differ in their sensitivity to antibiotics, the optimal concentration (pre-transfection/transduction) should be determined. In the following protocol the lowest concentration that provides adequate selection is determined for the experimental cell line.

Puromycin and blasticidin have a similar range of concentration that is toxic to most cell lines. So, the same kill curve can be used for both.

### *Required materials*

- Complete media experimental cell line
- Puromycin (1.25 µg/µl stock solution)
- Blasticidin (1.25 µg/µl stock solution)
- 24-well tissue culture plate

### *Equipment*

- Automatic pipetter /Pipette-aid
- Disposable or autoclaved tissue culture pipettes
- CO<sub>2</sub> cell culture incubator at 37°C

### Protocol

1. Plate  $5 \times 10^4$  cells per well in 11 wells of a 24-well tissue culture plate using media without puromycin.

Prepare puromycin dilutions in culture media for antibiotic titration as shown in Table 1. Use a puromycin stock solution of 1.25  $\mu\text{g}/\mu\text{l}$  stock solution.

**Table 1 Dilutions and volumes required for establishing optimal antibiotic concentration**

Volume of Puromycin Stock Solution Added ( $\mu\text{l}$ )	Total Volume of Media plus Antibiotic per 24 Well ( $\mu\text{l}$ )	Final Concentration ( $\mu\text{g}/\text{ml}$ )
0	500	0
0.2	500	0.5
0.4	500	1
0.6	500	1.5
0.8	500	2
1	500	2.5
1.2	500	3
1.6	500	4
2	500	5
3	500	7.5
4	500	10

2. Begin antibiotic selection the following day by replacing antibiotic free media with media containing the appropriate concentrations of puromycin.
3. Incubate cells with 5%  $\text{CO}_2$  at 37°C, or use conditions normal for your target cells.
4. Check cells daily to estimate rate of cell death.
5. Replenish the media containing the appropriate concentrations of puromycin every 2 days for 6 days.

*Note: The optimal puromycin concentration will kill the cells rapidly (2 - 4 days). This is particularly important for screens involving essential genes that may be selected against prior to the experiment.*

## 5. Transfection

Use the following procedure to transfect plasmid DNA into mammalian cells in a 24-well format. For other plate formats, scale up or down the amounts of DNA and OMNIfect reagent proportionally to the total transfection volume (Table 2).

**Adherent cells:** One day prior to transfection, plate cells in 500  $\mu$ l of growth medium without antibiotics so that cells will be 70–95% confluent at the time of transfection. The number of cells to plate will vary based on the double time.

**Suspension cells:** On the same day of transfection just prior to preparing transfection complex plate 160,000/well cells in 500  $\mu$ l of growth medium without antibiotics.

### *transEDIT CRISPR/Cas9 Vectors*

- transEDIT gRNA plus Cas9 Vectors (pCLIP-All), containing gRNA designed for your gene target of interest – target set of 3 vectors, bacterial glycerol stock
- transEDIT pCLIP-All Negative Control, bacterial glycerol stock

### *Additional Materials*

- 24-well tissue culture plates
- OMNIfect™ Transfection Reagent
- Cell culture complete medium for maintenance and passaging of experimental cell line (including serum and supplements)
- Antibiotic-free complete medium for maintenance and passaging of experimental cell line (including serum or supplements) without antibiotics such as pen-strep.
- Blasticidin S HCl antibiotic (Life Technologies, Cat# A11139-03)
- Puromycin Dihydrochloride (Life Technologies, Cat# A11138-03)
- Sterile 1.5 ml microfuge tubes
- Assays for assessing genome editing (e.g. Surveyor Assay)

### *Equipment*

- Automatic pipettor/Pipette-aid (for tissue culture)
- Disposable or autoclaved tissue culture pipettes
- CO2 cell culture incubator at 37°C
- Fluorescent microscope

### **Transfection complex preparation (Figure 3):**

Volumes and amounts are for each well to be transfected.

1. Plasmid DNA preparation: Dilute 0.5  $\mu$ g of plasmid DNA in a microfuge tube containing Opti-MEM® I Reduced Serum Media\*\*\* up to a total volume of 25  $\mu$ l.
2. OMNIfect reagent preparation: In a separate microfuge tube, add 1  $\mu$ l of OMNIfect into 24  $\mu$ l Opti-MEM® I Reduced Serum Media\*\*\* for a total volume of 25  $\mu$ l.
3. Final transfection complex: Transfer the diluted DNA solution to the diluted OMNIfect reagent (total volume = 50  $\mu$ l). Mix gently and incubate at room temperature for 10 minutes.

### Adding transfection complex to wells:

1. Add the 50  $\mu$ L of transfection complex to each well containing cells and medium.
2. Incubate cells at 37°C in a CO<sub>2</sub> incubator for 48-96 hours changing media as necessary.
3. Perform assay to determine genome editing efficiency.

\*\*\* Serum-free DMEM medium can also be used.




Figure 3: Transfection protocol for 24 well plates (volumes indicated are per well). To transfect the entire plate multiply all volumes and DNA amount by 24.

Table 2: Suggested amounts of DNA, medium and OMNifect for transfection of plasmid DNA into adherent and suspension cells.

Tissue Culture Plates	Surface Area per Well (cm <sup>2</sup> )	$\mu$ L Plating Medium per Well	$\mu$ g Plasmid DNA per Well	$\mu$ L OMNifect per Well	$\mu$ L Transfection Complex per Well†
6- well	9	2000	2 (in 100 $\mu$ L Opti-MEM® I)	4 (in 100 $\mu$ L Opti-MEM® I)	200
12-well	4	1000	1 (in 50 $\mu$ L Opti-MEM® I)	2 (in 50 $\mu$ L Opti-MEM® I)	100
24-well	2	500	0.5 (in 25 $\mu$ L Opti-MEM® I)	1 (in 25 $\mu$ L Opti-MEM® I)	50
96-well	0.3	200	0.1 (in 10 $\mu$ L Opti-MEM® I)	0.2 (in 10 $\mu$ L Opti-MEM® I)	10-20

† Total volume of the transfection complex is made up of equal parts of DNA solution and OMNifect solution.

## Transfection Optimization:

It is important to optimize transfection conditions to obtain the highest transfection efficiency with lowest toxicity for various cell types. The optimal ratio of OMNIfect to DNA is relatively consistent across many cell types. For further optimization try the following steps in order.

1. Use the recommended ratio of DNA:transfection reagent (at 1 µg DNA:2 µl OMNIfect), but vary the volume.
  - a. Start with a range of volumes that cover +20% to -20%.  
For example, in a 24-well plate a range of 40 µl to 60 µl of transfection complex would be added to the well. (The plating media would remain the same.)
2. If further optimization is needed, transfection efficiency and cytotoxicity may be altered by adjusting the ratio of DNA (µg) to OMNIfect reagent (µl). A range of ratios from 1:1.5 to 1:2.5 is recommended.

*Note: If transfection conditions result in unacceptable cytotoxicity in a particular cell line the following modifications are recommended:*

1. Decrease the volume of transfection complex that is added to each well.
2. Higher transfection efficiencies are normally achieved if the transfection medium is not removed. However, if toxicity is a problem, aspirate the transfection complex after 6 hours of transfection and replace with fresh growth medium.
3. Increase the cell density in your transfection.
4. Assay cells for gene activity 24 hours following the addition of transfection complex to cells.

## Selection - Enrichment for increased genome editing efficiency

After 24-48 hours, transfected cells can be selected using antibiotic resistance or fluorescent protein (FP) expression. The transEDIT pCLIP-All Lentiviral particles co-express several different selectable markers via a 2A “self-cleaving” peptide, including blasticidin resistance (Blast<sup>R</sup>) and puromycin resistance (Puro<sup>R</sup>) genes, as well as ZsGreen, and turboRFP (tRFP) FPs. Antibiotic selection ensures the removal of untransfected cells. Using FACS analysis to select for cells with highest fluorescent protein expression can further enrich for the population of cells with the highest frequency of genome editing.

### Antibiotic selection:

Refer to the protocol for the puromycin or blasticidin kill curve in section 5 to determine the optimal concentration for each cell line.


1. Incubate for 24-72 hours following transfection and then examine the cells microscopically for growth.
2. Begin the antibiotic selection by replacing the medium with complete medium supplemented puromycin or blasticidin.
3. Replace the selective media every 2-3 days. Monitor the cells daily and observe the percentage of surviving cells.
  - a. All untransfected cells should be removed within 3-5 days.
4. Collect samples for assay.

If selecting stably transfected cells, continue to replace the media containing puromycin. Observe the cells for approximately 7 days until you see single colonies surviving the selection. Colonies can be expanded for analysis.

**Fluorescence analysis:** If the vector expresses a fluorescent protein, incubate for 24-72 hours following transfection and then examine the cells microscopically for fluorescence expression. Sort the cells based on level of fluorescence and select the highest expressing population.

## 6. Packaging lentiviral particles

Some cell lines are resistant to transfection. Lentiviral particles offer an alternative delivery method. The pCLIP-All lentiviral vectors can be packaged into lentiviral particles for efficient delivery into target cell lines.



**Figure 4: Schematic depicting lentiviral packaging of lentiviral vectors**

When packaging lentivirus, the genetic elements required for assembly of replication incompetent viral particles are transfected into the cell in trans. The lentiviral transfer vector is co-transfected with the desired packaging vectors encoding the *env*, *gag* and *pol* protein into a packaging cell line. *gag*, *pol* and *env* provide the proteins necessary for viral assembly and maturation. The transfer vector contains sequences that will be packaged as the viral genome and code for the CRISPR/Cas9 components and selection cassette that will integrate into the target cell's genome. Viral particles are released from the packaging cell and can be harvested from the supernatant of the packaging cell. The resulting viral supernatant can be concentrated or applied directly to the targeted cell line.



### Considerations before packaging the lentiviral vector:

- The Non-Targeting Control should be used to determine the packaging and transduction efficiency of the target cell used.

### Required Materials

*Note: All plasmids are purified using endotoxin-free purification. All plasmids are resuspended in dH<sub>2</sub>O.*

- FuGENE6 (Promega, Cat. # E2691)
- Complete culture medium (DMEM + 10% FBS, 1X Pen/Strep, and 1X L-glutamine)
- OPTI-MEM I + GlutaMAX-I (Gibco, Cat. # 51985-034)
- Transfer vector dilute plasmid(s) to 0.2 µg/µl
- Lentiviral packaging mix
  - pCMV-dR8.2 - (Addgene)
  - pCMV-VSV-G - (Addgene)
- 10 cm tissue culture plates
- Filter, 0.45 µm made of cellulose acetate, or polysulfonate (low protein binding).
  - *Note: The filter used should not be nitrocellulose. Nitrocellulose binds proteins present in the membrane of lentivirus and destroys the viral particles.*

### Equipment

- Automatic pipetter/Pipette-aid
- Disposable or autoclaved tissue culture pipettes
- CO<sub>2</sub> cell culture incubator at 37°C

### Protocol

*Note: For smaller scale production, plate cells in one well of a 6-well plate and use 1/6<sup>th</sup> of the reagents.*

1. On the day prior to transfection, seed 4-5 x 10<sup>6</sup> HEK293T cells into a 100 mm plate in a total volume of 12 ml complete culture medium (DMEM + 10% FBS, 1X Pen/Strep, and 1X L-glutamine). It is recommended that the cells be 70- 80% confluent at the time of transfection.
2. Two hours prior to transfection remove the culture media and replace with 2 ml of fresh culture media containing no antibiotics.
3. Allow FuGENE6 (Promega, Cat. # E2691) and OPTI-MEM I + GlutaMAX-I (Gibco, Cat. # 51985-034) to come to room temperature.
4. Preparation of transfer vector and lentiviral vector packaging mix:  
*Note: All plasmids are resuspended in dH<sub>2</sub>O.*
  - a. Transfer vector – dilute plasmid(s) to 0.2 µg/µl
  - b. Lentiviral packaging mix (0.5 µg/ µl):
    - i. 100 µl pCMV-dR8.2 (0.5 µg/µl)
    - ii. 50 µl pCMV-VSV-G (0.5 µg/µl)
5. Mix FuGENE6 by inverting or vortexing briefly. In one well of a polystyrene round-bottom plate add the following:
  - a. 807 µl of OPTI-
  - b. 45 µl of FuGENE6
6. Incubate FuGENE6/OPTI-MEM mixture for 5 minutes at room temperature.
7. Add 30 µl transfer vector, 18 µl Lenti packaging mix, and 6 µl to the FuGENE6/ OPTI-MEM mixture. Mix immediately and incubate an additional 15 min at room temperature.

8. Add entire transfection mix dropwise to cells/culture. Swirl gently.
9. Return to incubator with 5% CO<sub>2</sub> at 37°C.
10. Collect viral particles (supernatant) 48 hours post-transfection.
11. Centrifuge the media briefly (800 x g for 10 min) or filter through a 0.45 µm filter to remove cellular debris.  
*Note: The filter used should be made of cellulose acetate, or polysulfonate (low protein binding), instead of nitrocellulose. Nitrocellulose binds proteins present in the membrane of viral particles and destroys them.*
12. Aliquot supernatant into sterile cryovials and store at -80°C.
  - a. Make 2 x 50 µl aliquots for titering and divide the rest into transduction aliquots.

*Note: The 50 µl aliquots will be used in the functional titering protocol. They should be stored at -80 °C overnight prior to titering to reflect any loss of function due to freeze/thaw cycle that will occur for the transduction aliquots. Freshly harvested viral particles from well-transfected cells should have a titer of approximately 1-5 x 10<sup>6</sup> TU/ml when measured on NIH-3T3 or HEK293T cells.*

## 7. Functional titer and transduction optimization

The number of viral particles used and the transduction efficiency will determine the average number of lentiviral integrations into the target cell genome. The following protocol is designed to evaluate functional titer of the virus produced in the previous section. Selection may be used to remove untransduced cells. A kill curve should be performed as described in section 5.

### Increasing transduction efficiency:

Optimizing transduction conditions can extend the utility of viral particles and limit cell toxicity. A number of variables influence transduction efficiency including components of the media, duration of transduction, cell type, cell health and plating density. It is possible to optimize many of these variables prior to the experiment.

- Serum is a known inhibitor of transduction and should be minimized (0 - 2%) in transduction media. For cells sensitive to low serum conditions either reduce the transduction time in low serum media or increase the transduction time in complete media.
- Transduction volume should be kept to a minimum. Media should barely cover cells.
- Extending transduction incubation times may increase efficiency. However, it may be necessary to increase the volume of media applied to the cells for transduction to limit the effects of evaporation.
- Hexadimethrine bromide (Polybrene) is a cationic lipid known to enhance viral particle binding to the surface of many cells types. A range of concentration (0 - 10 µg/ml) should be tested to determine the highest transduction efficiency that can be achieved with minimal cell toxicity.
- Cell density may influence transduction efficiency. Plate cells at a range of densities to determine its effect on your cell line. Rapidly dividing cells are often transduced more efficiently.

### Determining Functional Titer

Functional titer must be determined using the experimental cell line to ensure optimal transduction. The functional titer is the number of viral particles, or transducing units (TU), able to transduce the target cell line per volume and is measured in TU/ml. Cell type, media components and viral production efficiency influence functional titer. It should therefore be calculated for every batch of virus produced and every cell line.

Once a baseline titer is known, this protocol can be used to further optimize transduction efficiency. To do so, follow this procedure and alter variables known to influence transduction efficiency.

- The following protocol evaluates titer by manually counting ZsGreen positive colonies. Alternate methods for determining titer are provided in Appendix 3.
- Transduction optimization should be done with the with Non-Targeting Control viral particles.
- If the packaging protocol was followed for viral particle production, use the titering aliquots made in the virus production section above to determine the titer.
- HEK293T cells are readily transduced under standard conditions and are included in the protocol as a positive control for transduction.

### Required materials

- HEK293T cells
- Complete media for HEK293T cells and experimental cell line
- Serum free media for each cell line
- 24-well tissue culture plate
- Lentiviral particles (Harvested or purchased)
- Microcentrifuge tubes
- Polybrene

### Equipment

- Automatic pipetter /Pipette-aid
- Disposable or autoclaved tissue culture pipettes
- CO<sub>2</sub> cell culture incubator at 37°C
- Fluorescent microscope with GFP filter (refer to Appendix3 for alternative methods that do not require this)

### Protocol

1. Plate cells (HEK293T and experimental cell line) 24 hours prior to transduction in a 24 well plate. Plate at a density of  $7 \times 10^4$  cells per well in 12 wells with complete media. Incubate for 24 hours with 5% CO<sub>2</sub> at 37°C.
2. Prepare a serial dilution series with serum free media and viral supernatant as shown in Table 3 and Figure 5.
  - a. Set up 5 sterile microcentrifuge tubes.
  - b. Add 160  $\mu$ l of serum free medium to each tube containing 5-8  $\mu$ g/ml Polybrene.
  - c. Add 40  $\mu$ l of viral stock to the first microfuge tube.
  - d. Mix well by gently pipetting up and down (10 - 15 times) without creating bubbles and discard the tip.
  - e. Transfer 40  $\mu$ l from the first microcentrifuge tube to the second tube. Mix well and discard the tip.
  - f. Repeat the procedure for the 4 remaining tubes.
  - g. Incubate at room temperature for 10-15 minutes.
3. Remove media from each well.
4. Add 200  $\mu$ l of serum free media to each well containing cells.
5. Add 25  $\mu$ l from each viral dilution to two wells (225  $\mu$ l final volume) for a total of 10 wells per cell line. The remaining two wells (without viral particles) should be evaluated as negative controls.
6. Rock plate gently a few times to mix.
7. Incubate overnight with 5% CO<sub>2</sub> at 37°C.
8. Replace the viral supernatant with complete media and allow cells to grow for 48 hours.
9. Count the number of colonies expressing ZsGreen. A colony consisting of multiple cells should be counted as a single transduction event.
 

*Note: Counting 50-200 colonies in a well is sufficient to provide accurate titers.*
10. Use the calculation below and Table 3 to determine functional titer. (Alternate methods for calculating are described in Appendix 3.)

$$(\text{Number of colonies}) \times (\text{Dilution factor}) \div 0.025 \text{ ml} = \frac{\text{TU}}{\text{ml}} \text{ Functional titer}$$

For Example:

If the average number of colonies counted in well A4 and B4 is 70 the titer is calculated as follows:

$$70 \text{ colonies} \times 625 \div 0.025 \text{ ml} = 1.75 \times 10^6 \text{ TU/ml}$$

## Dilution table and schematic for titration protocol

**Serial dilution**

Add 25 µl to each well

	1	2	3	4	5	6	
<b>A</b>	●	●	●	●	●	○	(-) Control
<b>B</b>	●	●	●	●	●	○	(-) Control
<b>C</b>	●	●	●	●	●	○	(-) Control
<b>D</b>	●	●	●	●	●	○	(-) Control

HEK293T  
Experimental cell line

**Table 3 Dilution factors for calculating viral titer**

Tube	Viral particles	Dilution medium	Dilution factor
1	40 µl (from titer aliquot)	160 µl	5
2	40 µl (from Tube 1)	160 µl	25
3	40 µl (from Tube 2)	160 µl	125
4	40 µl (from Tube 3)	160 µl	625
5	40 µl (from Tube 4)	160 µl	3125
6	0 µl		n/a

**Figure 5 Schematic of serial dilution for viral particle titering. (-) indicates untransduced control.**

**Example:**

Typical virus production will yield  $1-5 \times 10^6$ . The expected number of fluorescent colonies for a viral titer of  $1 \times 10^6$  would yield the following number of fluorescent colonies in titering assay:

Tube	1	2	3	4	5	6
Dilution	1/5	1/5	1/5	1/5	1/5	n/a
Diluted titer TU/ml	200,000	40,000	8,000	1,600	320	0
ml transduced cells	0.025	0.025	0.025	0.025	0.025	0
Fluorescent colonies expected	5,000	1,000	200	40	8	0

Counting 50-200 colonies is sufficient for an accurate measure of titer.

## V. Transduction Guidelines & Protocols

This protocol provides a basic outline of the transduction process. The following should be optimized prior to transduction:

- Transduction media: % Serum, Polybrene  $\mu\text{g}/\text{ml}$
- Time exposed to transduction media: hours or overnight
- Selection media:  $\mu\text{g}/\text{ml}$  puromycin

### *Required materials*

- Complete media for experimental cell line
- Selection media: complete media for experimental cell line supplemented with puromycin
- Transduction media containing viral particles (optimized for serum and Polybrene concentration)

### *Equipment*

- Automatic pipetter /Pipette-aid
- Disposable or autoclaved tissue culture pipettes
- CO<sub>2</sub> cell culture incubator at 37°C
- Assay specific equipment

### *Protocol:*

#### *Prepare cells*

1. Plate cells such that they are actively dividing and 60 - 70% confluent at the time of transduction.
2. Feed cells with complete media 3 - 4 hours prior to transduction.
3. Make transduction media just prior to transduction.

#### *Transduce cells*

4. Exchange media with transduction media.  
*(Note: media should be serum free for maximum transduction efficiency. Alternatively, see section 7 for information on transduction optimization.)*
5. Incubate cells 12 - 24 hours in transduction media.
6. Replace transduction media with complete media (no puromycin).

#### *Puromycin selection*

7. Allow cells to grow for 48 hours.
8. Replace media with selection media.
9. Continue feeding cells selection media until untransduced cells have been removed.


#### *Analysis*

10. Analyze knockout efficiency in population. Determine cellular phenotype or harvest cell for gene expression analysis according to your experimental design.

## Appendices

### Appendix 1 - pCLIP-All-EFS-Puro

Created with SnapGene®



Element	Start	Stop	Element	Start	Stop
CMV-LTR	23	667	FLAG	7056	7079
HIV-1 Psi	746	840	P2A	7089	7145
RRE	1333	1566	PuroR	7146	7742
cPPT/CTS	2093	2210	MCS	7744	7749
U6 promoter	2261	2501	WPRE	7756	8347
gRNA scaffold	2531	2606	3'LTR	8552	8787
EFS-NS Promoter	2648	2880	SV40	8881	9210
Cas9	2904	7007	ori	9299	9884
nucleoplasmin NLS	7008	7055	AmpR	10055	10915
			AmpR promoter	10916	11020

Figure 5: Detailed map of the pCLIP-All-EFS-Puro vector. The pCLIP vectors includes options for additional promoters and selection markers. See the website for detailed vector information for the other vectors.

## Appendix 2 – Safety and handling of lentiviral particles

Recombinant lentivirus is considered a Biosafety Level 2 organism by the National Institutes of Health and the Center for Disease Control and Prevention. However, local health and safety regulations should be determined for each institution.

For more information on Biosafety Level 2 agents and practices, download Biosafety in Microbiological and Biomedical Laboratories (BMBL), Fifth Edition (Revised December 2009) published by the U.S. Department of Health and Human Services Centers for Disease Control and Prevention and NIH. The publication can be found here:

<http://www.cdc.gov/biosafety/publications/bmbl5/>.

If additional measures are needed, review biosafety guidance documents such as the NIH’s “Biosafety Considerations for Research with Lentiviral Vectors” which refers to “enhanced BL2 containment”. More information can be found through the NIH Office of Biotechnology Activities web site ([http://oba.od.nih.gov/rdna\\_rac/rac\\_guidance\\_lentivirus.html](http://oba.od.nih.gov/rdna_rac/rac_guidance_lentivirus.html))

### Summary of Biosafety Level 2 Practices

The following is meant to be a summary of Biosafety Level 2 practices and should not be considered comprehensive. A full account of required practices should be determined for each institute and/or department.

#### Standard microbiological practices

- Limit access to work area
- Post biohazard warning signs
- Minimize production of aerosols
- Decontaminate potentially infectious wastes before disposal
- Use precautions with sharps (e.g., syringes, blades)
- Review biosafety manual defining any needed waste decontamination or medical surveillance policies

#### Safety equipment

- Biological Safety Cabinet, preferably a Class II BSC/laminar flow hood (with a HEPA microfilter) used for all manipulations of agents that cause splashes or aerosols of infectious materials; exhaust air is not recirculated
- Protective personal equipment includes: protective laboratory coats, gloves, face protection if needed

#### Facilities

- Autoclave available for waste decontamination
- Chemical disinfectants available for spills



### Appendix 3 - Alternate methods for titering

1. Puromycin titering by selection and colony counting:
  - a. Begin the antibiotic selection by replacing the media with complete media supplemented using the optimal puromycin concentration determined in “puromycin kill curve”
  - b. Continue feeding and observe the cells for approximately 7 days until you see single colonies surviving the selection. The negative control should have no surviving cells.
  - c. Use a microscope to count the number of surviving colonies.
  - d. Calculate the functional titer using the number of colonies visible at the largest dilution that has colonies.

$$(Number\ of\ colonies) \times (dilution\ factor) \div 0.025\ ml = \frac{TU}{ml}\ functional\ titer$$

2. ZsGreen titering by FACS analysis
  - a. When calculating the percentage of transduced cells **use the number of cells present on the day of transduction as the denominator.**
  - b. Only analyze wells that have < 20% of cells transduced to ensure none of the cells have been transduced with more than one viral particle.

$$\frac{(Number\ of\ cells\ at\ transduction)}{(Number\ of\ ZsGreen\ positive\ cells\ in\ well)} \times (dilution\ factor) \div 0.025\ ml = \frac{TU}{ml}\ functional\ titer$$

## Limited use licenses

This product is covered by several limited use licenses. For updated information please refer to [www.transomic.com/support/productlicenses](http://www.transomic.com/support/productlicenses)

## Contact Information

For more information or technical support please visit our website at [www.transomic.com](http://www.transomic.com) or contact us via email or phone.

### Corporate Headquarters

transOMIC technologies inc.  
601 Genome Way, Suite 1222  
Huntsville, AL 35806 USA  
Phone: 866-833-0712 Fax: 256-327-9515  
E-mail: [support@transomic.com](mailto:support@transomic.com)

Unless otherwise expressly stated on the Product or in the documentation accompanying the Product, the Product is intended for research only and is not to be used for any other purpose, including without limitation, unauthorized commercial uses, in vitro diagnostic uses, ex vivo or in vivo therapeutic uses.

© 2015 transOMIC technologies Inc. All rights reserved.